


EXPLODED VIEW



RTS LOST

PART NO.	DESCRIPTION	QTY
1	HOUSING	1
2	VALUE PLUG	1
3	O-RING	1
4	SPRING	1
5	THROTTLE VALVE	1
6	O-RING	1
7	ROLL PIN	1
8	VALVE BUSHING	1
9	THROTTLE LEVER	1
10	END PLATE CAP	1
11	BALL BEARING	1
12	REAR END PLATE	1
13	VANES	4
14	ROTOR	1
15	PIN	1
16	CYLINDER	1
17	FRONT END PLATE	1
18	BEARING	1
19	WASHER	1
20	THREAD RING GEAR	1

PART NO.	DESCRIPTION	QTY
21	IDLER GEAR	3
22	IDLER GEAR PLATE	1
23	IDLER GEAR PIN	3
24	CLAMP NUT	1
25	SPACER	1
26	RATCHET HOUSING	1
27	PIN	1
28	NEEDLE BEARING	1
29	CRANK SHAFT	1
30	DRIVE BUSHING	1
31	YOKE	1
32	RATCH ANVIL	1
33	WASHER	1
34	THRUST WASHER	1
35	RETAINER RING	1
36	RATCHET PAWL	1
37	LOCK PIN	1
38	SPRING	1
39	REVERSE BUTTON	1
40	AIR INLET	1