


# PUNCH/FLANGE TOOL

STOCK NO.  
662

## EXPLODED VIEW



Index No.	Parts No.	Description	Qty. Per
1	0706A01	Body	1
2	0706A02	"O" Ring	1
3	0706A03	Back up Ring	2
4	0706A04	Spacer	1
5	0706A05	Spring	1
6	0706A06	Piston Rod	1
7	0706A07	Washer	2
8	0706A08	Piston	1
9	0706A09	Nut	1
10	0706A10	"O" Ring	1
11	0706A11	Throttle Lever	1
12	0706A12	Pin Valve	1
13	0706A13	"O" Ring	1
14	0706A14	"O" Ring	1
15	0706A15	Throttle Bushing	1
16	0706A16	"O" Ring	1
17	0706A17	Throttle Valve	1
18	0706A18	"O" Ring	1
19	0706A19	Spring	1
20	0706A20	Lever Pin	1

Index No.	Parts No.	Description	Qty. Per
21	0706A21	Clamp A	1
22	0706A22	Clamp B	1
23	0706A23	Seal	1
24	0706A24	Set Screw	1
25	0706A25	Punch Die IE	1
26	0706A26	Guide Bushing	1
27	0706A27	Washer	11
28	0706A28	Punch	1
29	0706A29	Guard	1
30	0706A30	Screw	2
31	0706A31	Oil Seal	1
32	0706A32	Back up Ring	1
33	0706A33	"O" Ring	1
34	0706A34	Oil Plug	1
35	0706A35	"O" Ring	1
36	0706A36	Lock Nut	1
37	0706A37	"O" Ring	1
38	0706A38	Back up Ring	1
39	0706A39	Piston	1
40	0706A40	Inlet Bushing	1